

# 623A, 623B, 624A, & 625A Capacitance Manometer Pin-outs

Terminal Block 1 (TB1)

Pin	Description
1	Power Common
2	Signal Common
3	Signal Output
4	-15 VDC
5	+15 VDC
Note:	Chassis Ground. to screw labeled Chassis

Terminal Block 2 (TB2)

Pin	Description
1	Trip Point A Level (0 to 10 Volts)*
2	Trip Point A Relay, Normally Closed
3	Trip Point A Relay, Common
4	Trip Point A Relay, Normally Open
5	Trip Point B Relay, Normally Open
6	Trip Point B Relay, Common
7	Trip Point B Relay, Normally Closed
8	Trip Point B Level (0 to 10 Volts)*
*Note:	Use pin 2 of TB1 for trip point signal common